VIBRATION PAD

Part & Function

plug
Wire
Vibrator

Setup

This vibration pad must be worked with the Multi-Alert system (DCX-800vib) when using the vibration function.

Vibration Pad On/Off
Vibration out
DC jack
12V ready indicator
Pad On inducator

DC jack: If using the vibration pad, It must be connected a 12V 400mA AC/DC adaptor to this jack.

12V ready indicator: This indicator will lit up, when the 12V adaptor is connected correctly.

Vibration pad on/off: Slide this switch to turn on or turn off the vibration function.

Pad on indicator: If the Vibration pad on/off switch is slide to on position , this LED indicator will lit up to indicate Vibration function is ready.

Vibration out: Plug vibration pad to this jack.