


USER MANUAL

HAX-700

Parts and Function







- 1. Batteries compartment
- 2. Battery Door
- 3. Regenerates new code button.
- 4. Power on/off switch
- 5. Transmitter On/off switch. 6. Alert sound selector. 7. Light on/off switch. 8. Volume control.

Power






Remove the screw and slide to open the battery cover

31.5mm

Installation

Flip to open the cover



Insert 3 AAA bateries to the battery compartment and close the battery cover

Settina

Select the switches inside the battery compartment to do unit setting. 1. Power 也.

- Switch to off **o** position when do not use this device. 2. Transmitter On/Off switch 3.
 - On I: Send a trigger signal to receiver when triggered Off **o** : Do not send signal to receiver when triggered.
- 3. Sound selector

Select the suitable sound by slide this switch to • or • position 4. Light On/Off Q

- Turn the flash light on 1 or off by slide this switch.
- 5. Volume control () :
 - You can select High II / Low I / No sound o by slide this switch.
- 6 Regenerate a new code R

If the RF code is conflict, press the button in the pin hole to regenerate a new code

Pairing with receiver

This unit can work stand alone or work with the wireless receiver. If work with the receiver, you need to pairing with the receiver follow to the manual of the receiver.

Operation



Using the rope attach to the object that you do not want other people move it

Once the magnetic is out of position, the alarm will acticvated

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the use

- is encouraged to try to correct the interference by one or more of the following measures
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver

* Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.

Holding Bracket 9. Flasher

10. Speaker 11. LED indicator. 12. Magnetic holder









